



**L L291-SERIES TOP GUN HOME THEATER**

Overall: h41 d43 on most pieces width varies

Inside: d22 ah25.5 sh22.5

Wall Clearance: Zero Full Extension: 68

Attached backs-loose not available / Removable Aluminum cupholders (choice of colors: Ebony or Nickel) / Naples bun feet / Connectors / Requires a power outlet. Plug directly into an outlet or surge protected power strip. Do not use an extension cord or regular power strip. / Rechargeable battery optional

**As Shown: L291-11ZM LAF Chair / L291-01ZM Chair / L291-12ZM RAF Chair**

*Available in fabric. No nails standard.*



**L L292-SERIES TOP GUN HOME THEATER**

Overall: h41 d43 on most pieces width varies

Inside: d22 ah25.5 sh22.5

Wall Clearance: Zero Full Extension: 69






1/2" nails head-to-head / Removable Aluminum cupholders (choice of colors: Ebony or Nickel) / Semi-attached, knife edge back cushions / Loose back cushions are not available / Connectors / Requires a power outlet. Plug directly into an outlet or surge protected power strip. Do not use an extension cord or regular power strip. / Rechargeable battery optional

**As Shown: L292-11ZM LAF Chair / L292-01ZM Chair / L292-12ZM RAF Chair**

*Options Shown: 1/2" Natural Brass nail color.*

*Available in fabric. No nails standard.*

DIAGRAMS NOT TO SCALE.



**IMPORTANT**

A DIAGRAM OUTLINING INDIVIDUAL PLACEMENT OF CHAIRS IN EACH ROW MUST BE SUBMITTED BEFORE AN ORDER IS PLACED INTO PRODUCTION. THIS ENSURES PROPER PLACEMENT OF CONNECTORS, AND CONFIRMS THAT THE CORRECT PIECES HAVE BEEN ORDERED FOR EACH ROW OF THEATER SEATING.